

Gasmate®

HIGH OUTPUT COOKER & POT SET

Model No. CS2100SL



- Suitable for outdoor cooking where larger pots and a higher heat output is required – Convenient for cooking sauces, crabs, lobster or any shell fish
- Flame protection ring
- Includes convenient carry case
- Includes thermometer to achieve ideal cooking temperature
- Pots are made from durable aluminium
- Hose and regulator included
- Propane/ULPG use only
- Gas certified to Australia & New Zealand Standards

! OUTDOOR USE ONLY

SafeLok®

LCC27 REGULATOR SUPPLIED

This LCC27 Regulator can only be used with the new safer industry standard LCC27 Gas Cylinder Connection.

Important: Retain these instructions for future use.

GENERAL WARNINGS

⚠ WARNING

- This appliance shall only be connected to a cylinder certified to AS2469 standards.
- This appliance shall only be used with the Hose & Regulator Assembly supplied, Regulator is set to 150kPa and is not adjustable – Do Not Modify.
- This appliance is designed for outdoor use only and must be operated away from any flammable material or surfaces and materials.
- This appliance is to be stored in a dry and well-ventilated location free from direct sunlight.
- Do not store when appliance is still connected to the cylinder.
- Make sure that the cylinder is disconnected and is stored in a well-ventilated area, free from direct sunlight, heat and ignition sources.
- If being stored indoors, ensure that the location complies with the standard AS/NZS1596.
- This appliance must only be serviced by an authorised service agent, contact Sitro Group for assistance with repairs and spare parts.
- NEVER ALLOW TO BOIL DRY - always maintain liquid at the fill level during use.

DANGER

- During operation all surfaces will be extremely hot and should not be touched or handled.
- Do not use the appliance if it is leaking, damaged or does not operate properly.
- Handle with care even after brief use, always pick up using the legs not the cylinder.
- It may be hazardous to attempt to fit other types of gas containers or cartridges.
- Use only in well ventilated areas.
- **Always operate appliance a minimum of 900mm from flammable materials, walls and 1200mm from the ceiling.**
- Do not use adaptors. Do not modify appliance to fit other connectors or cylinders.
- Do not use multiple appliances to heat a single utensil.
- Children must be supervised by an adult at all times.
- **Never leave appliance unattended when operating.**
- Use as a cooking appliance only, not to be used as heater or modified for any other reason.
- Avoid boil over and spills on to burners.
- NEVER ALLOW TO BOIL DRY - always maintain liquid at the fill level during use.

⚠ CARBON MONOXIDE HAZARD

Using this appliance in an enclosed space may cause DEATH.

Do not use in caravans, tents, marine craft, cars, mobile homes or similar locations.

IMPORTANT

- Use outdoors only.
- Keep children away at all times.
- CAUTION: Accessible parts may be very hot. Please take care when handling or moving the appliance.
- Read these instructions for use carefully. Familiarise yourself with the appliance before connection it to its gas cylinder. Keep these instructions for future reference.
- The supplied LCC27 regulator and hose will only suit the safe LCC27 gas cylinder connection.
 - Only use in well ventilated areas.
 - Carbon monoxide hazard – Using this appliance in an enclosed space may cause death.
- **Do not use in caravans, tents, marine craft, cars, mobile homes or similar locations.**
- **This appliance shall only be used in an above ground open-air situation with natural ventilation, without stagnant areas, where gas leakage and products of combustion are rapidly dispersed by wind and natural convection.**
- Ensure the appliance is set up on a level and stable surface.
- Do not move the appliance while in use or when hot.
- Only cooking vessels with a minimum diameter of 200mm and a maximum of 300mm are to be used with this appliance.
- Take care that the primary air intakes, located on the burner tube of this appliance are not obstructed, or that air flow is restricted by placing items or other appliances close to or adjacent to the inlets.
- If you smell gas, immediately turn the gas off at the cylinder and move the appliance and cylinder to a well-ventilated area outside, keeping well away from sources of heat such as naked flames and pilot lights.
- Do not attempt to move or relocate the appliance when it is operating, extinguish the burner and allow to cool, disengage the gas cylinder then move the appliance.

CHECKING FOR GAS LEAKS

- Check that all connections are tight and that the gas cylinder connection has been tightened before you turn the cylinder gas valve on.
- NEVER check for leaks with a flame or pilot light.
- Using Companion Gas Leak Detection Spray or soapy water, coat all connections, if bubbles appear turn the cylinder gas control off and retighten the connection before re-testing.
- Inspect the appliance regularly for signs of wear, leaks or incorrect operation.

If symptoms such as flaring of the burner, issues with lighting, damages to hoses or connections or leaks from seals or gas controls are identified do not attempt to repair, return to your authorised stockist for service and maintenance.

CHANGING GAS CYLINDER

- To check if gas remains in the cylinder, disconnect from the appliance and hold the cylinder in a vertical position then shake from side to side, if there is a sound or feel of liquid movement inside, the cylinder contains gas.
- When changing gas cylinders ensure this is conducted outside in a well-ventilated location free from people, animals and ignition sources such as naked flames, pilot lights and electrical equipment with heaters or elements.

USING THIS HIGH OUTPUT COOKER

- **Ensure the pot is filled to the “fill” line with water/liquid before placing on the cooker stand.**
- **Never let the water/liquid drop below the “fill” line during cooking, carefully top up with water/liquid during the cooking process.**
- **Never let the pot boil dry, the pot will become damaged extremely quickly.**
- Never use in boats, utes, cars, caravans or similar locations.
- Once boiling you can turn the gas control to low, this will keep the water/liquid simmering rather than rapidly boiling.

PARTS LIST



Part No.	Description	Qty
1	Steamer Pot	1
2	Boiler Pot	1
3	Burner Frame	1
4	Carry Bag	1
5	Hose and 150kPa Regulator (LCC27 Safe Lok)	1
6	Thermometer	1
7	Heat Reflector	1
8	Burner	1
9	Wing Nuts	2
10	Gas Valve Assembly	1

GENERAL ASSEMBLY



Connecting & Disconnecting to the Gas Source

Familiarise yourself with the general information and safety guidelines located in this manual. Note: Remove any transit protection material and dispose of this in an environmentally friendly way.



ASSEMBLY

Review the contents of the package. Make sure all listed components are included.

1. Install the burner and heat reflector into the steel frame, using the wing nut.



2. Align the Burner Tube Cover with the gas control assembly positioned at the end of the burner and then secure with the Wing Nuts.



3. Attach the LP Gas hose to the Gas Valve Assembly using a spanner – do not over tighten. Refer to below for specific details and images.

CONNECTION

1. Check that the cylinder is filled, a sloshing sound will be heard when shaken.
2. Check for any damage to either the cylinder connection or the hose before using. NEVER attempt to use damaged equipment.
3. Connect hose to gas control and tighten with a spanner - take care not to overtighten (See Pic. A).
4. Connect the LCC27 regulator to the cylinder valve and tighten (See Pic. B)
5. Before using turn the gas cylinder valve on and spray soapy water on all connections to check for leaks. If a leak is detected turn the valve off, retighten all connections and retest.



LIGHTING THE COOKER


1. Turn the gas cylinder valve on, in an anti-clockwise direction for one full turn.




2. Using long BBQ matches or gas lighter, position close to the edge of the burner to be ignited, slowly turn the gas control in an anti-clockwise direction approximately 1/4 of a turn.

Before lighting ensure that the stand with burner fitted is on flat stable ground and is 900mm away from flammable walls and 1200mm away from flammable ceilings or trees. Also never use in boats, utes, cars, caravans or similar locations.

Always ensure the pot is filled with water up to the "fill" line before lifting on to the burner and stand. Never allow the pot to boil dry. Always maintain the water to the fill line during use. The whole appliance gets very hot during use allow to cool totally before packing away.



3. If the burner does not ignite, turn the gas control in the clockwise direction to the "OFF" position and allow the residual gas to disperse before attempting to reignite the burner.




GENERAL ASSEMBLY

ADJUSTING HEAT OUTPUT

1. Turn the gas control in an anti-clockwise direction to achieve a higher flame and in the clockwise direction for a lower flame or to turn off.

Note: Locate the gas cylinder away from your cooker to ensure it is not subjected to radiant heat.


Always ensure the pot is filled with water up to the "fill" line before lifting on to the burner and stand. Never allow the pot to boil dry. Always keep the water up to the fill line during use.




TURNING THE APPLIANCE OFF

If the appliance is no longer to be used and to reduce the risk of blocked gas jets caused by excess gas being left in the hose, all remaining gas must be expelled from the hose assembly.

1. With the flame still operating, turn the valve on the gas cylinder in the clockwise direction until it is off. Allow the flame to burn down then extinguish once all remaining gas in the hose has been used.



2. Turn the gas controls on the appliance clockwise to the "OFF" position.



STORING APPLIANCE

1. Wait for appliance to cool and disassemble all parts and place in pot.
2. Position frame over pot and allow to settle.
3. Place in storage bag.




SAFETY INSTRUCTIONS


This appliance shall only be used in an above ground open air situation with natural ventilation without stagnant areas where gas leakage is rapidly dispersed by wind and natural convection.

Any enclosure in which appliance is used should comply with one of the following:

- A. An enclosure with walls on all sides, but with no overhead cover.






- B. Within a partial enclosure that includes an overhead cover and no more than two walls.



- C. Within a partial enclosure that includes an overhead cover and more than two walls, the following must apply:

1. At least 25% of the total wall area is completely open.
2. 30% or more in total of the remaining wall side, back and front wall areas is open and unrestricted.
3. In the case of balconies, 20% or more of the total wall area must remain open and unrestricted.



The figures shown are diagrammatic representations of outdoor areas. Rectangular areas have been used in these figures - the same principles apply to any other shaped areas.

CARE INSTRUCTIONS

As with all appliances, proper care and maintenance will keep them in top operating condition and prolong their life. By following these cleaning procedures on a timely basis, your appliance will be kept clean and working properly with minimum effort.

Using warm soapy water with a mild detergent wipe down all surfaces and areas of the appliance, taking care not to allow water to enter the burner outlets or aeration holes located in the burner tube.

DO NOT submerge the appliance in a sink or bowl.

DO NOT use abrasive cleaners or bleach.

MAINTENANCE & SERVICE

During operation if it is noted that the burner flame is unstable, is changing colour from blue to yellow or has a distinct smell it is important that you contact Sitro Group for your local authorised gas appliance repairer for inspection. Periodically check the gas control is tight and has no leaks, follow the testing for leaks procedure. Check the gas connection and regulator for any signs of wear or damage, if identified contact customer service for a replacement assembly immediately.

For further information or assistance please contact Customer Service.

SPECIFICATIONS

Model No.	CS2100	
Description	High Output Cooker & Pot Set	
Gas Type	Propane (Australia Only)	ULPG (New Zealand Only)
Injector	1.00mm	0.88mm
Pressure	150kPa	
Consumption	90 MJ/h 1786 g/h	78 MJ/h 1547 g/h
Certificate	AGA 8821 G	

For any queries or assistance, call:



Customer Service
(Australia Only)

1300 174 876

Hours of operation:

Monday to Friday 8.00am - 5.00pm EST

Do not return to place of purchase.

Keep your purchase receipt, this will be required to make any claims under the 12 month warranty.

Important: Retain these instructions for future use.

NEW ZEALAND ONLY

For warranty details visit www.gasmate.co.nz For warranty claims return to place of purchase.

Your purchase receipt will be required for warranty claims.