





PHOENIX BBQ AND SIDE BURNER MODULES

NOVA MK2



Phoenix BBQ Module
Model No. BQ3058NV



Phoenix Side Burner Module
Model No. BQ3059NV


IMPORTANT: RETAIN THESE INSTRUCTIONS FOR FUTURE USE.

For the most up-to-date version of this manual, please visit the product page at gasmate.com.au, as updates and improvements may be made periodically.

Gasmate® is a registered trademark of Sitro Group Australia Pty Ltd www.gasmate.com.au
Aber Living, N.Z. www.gasmate.co.nz

PHOENIX BBQ MODULE


SCREW PACK LIST

Screw Packs	Description	Quantity
B1	 M8 x 15 Bolt	16
	 Ø8 Spring Washers	16
	 Ø8 Flat Washers	16
B2	 M5 x 10 Bolt	70
B3	 M5 x 30 Bolt	5


Parts No.	Description	Quantity
1	Bottom panel	1
2	Casters without brake	2
3	Casters with brake	2
4	Left panel	1
5	Back panel	1
6	Right panel	1
7	Cylinder holder assembly	1
8	Middle panel	1
9	Top panel	1
10	Shelf	1
11	Rear top bar	1
12	Outer heat shield panel	1
13	Left heat shield panel	1
14	Right heat shield panel	1
15	Front heat shield panel	1
16	Back heat shield panel	1
17	Top left panel	1
18	Top right panel	1
19	Front bar	1
20	Front beam	1
21	Left door	1
22	Right door	1

PHOENIX BBQ MODULE

CASTERS ASSEMBLY




LEFT, RIGHT AND BACK PANEL ASSEMBLY




PHOENIX BBQ MODULE

CYLINDER HOLDER ASSEMBLY




MIDDLE PANEL ASSEMBLY




PHOENIX BBQ MODULE

TOP PANEL ASSEMBLY




TOP REAR BAR AND SHELF ASSEMBLY



PHOENIX BBQ MODULE


BBQ HEAT SHIELD ASSEMBLY

Remove the hotplate, grill plate and flame tamers from the BBQ




Insert the outer heat shield panel to the left side cavity of the BBQ

Position the front, left, right and back heat shield panels into the firebox as shown. Then tighten the panels using the bolts provided from Screw Pack B2



PHOENIX BBQ MODULE


FRONT AND SIDE PANELS ASSEMBLY





Assemble the front bar, front beam, left and right panels as shown.

Keep these bottom screws half loosen and leave about 5mm gap.

Position the BBQ in place and adjust the feet height, so that it sits flush with the top of the rear top panel.




PHOENIX BBQ MODULE




PHOENIX BBQ MODULE

DOORS ASSEMBLY




CONNECTING MODULES



PHOENIX SIDE BURNER MODULE


SCREW PACK LIST

Screw Packs	Description	Quantity
B1	 M5 x 15 Bolt	16
	 Ø5 Spring Washers	16
	 Ø5 Flat Washers	16
B2	 M5 x 10 Bolt	40
	 M5 Nutsert	6

Parts No.	Description	Quantity
1	Bottom panel	1
2	Casters without brake	2
3	Casters with brake	2
4	Left panel	1
5	Back panel	1
6	Right panel	1
7	Shelf	1
8	Front bar	1
9	Top plates	2
10	Rear top bar	1
11	Door	1


PHOENIX SIDE BURNER MODULE

CASTERS ASSEMBLY




LEFT, RIGHT AND BACK PANEL ASSEMBLY

M5 x 10 bolts from
Screw Pack B2




PHOENIX SIDE BURNER MODULE

SHELF ASSEMBLY




FRONT BEAM ASSEMBLY




PHOENIX SIDE BURNER MODULE

TOP PLATE ASSEMBLY




TOP REAR BAR ASSEMBLY




Insert the pin on the bottom of the door into the hole on the bottom panel. Press then release the spring loaded pin to let it pop into the upper hole of the door.

PHOENIX SIDE BURNER MODULE

POSITION THE BBQ




CONNECTING MODULES



PHOENIX SIDE BURNER MODULE

CONNECTING MODULES



WARNING

ACCESSIBLE PARTS OF THE TROLLEY COULD BE HOT DURING USE.
KEEP CHILDREN AND OTHERS WHO NEEDS SUPERVISION AT A SAFE DISTANCE.
DO NOT MOVE THE TROLLEY WHILE IN USE.

For any queries or assistance call

AUSTRALIA

Customer Service
1300 174 876

Hours of operation:
Monday to Friday 8am - 5pm EST

NEW ZEALAND

For warranty details visit
www.gasmate.co.nz

Do not return to place of purchase.

Keep your purchase receipt, this will be required to make any claims under the 1 year warranty.

The Gasmate logo is displayed within a black rectangular box. The word "Gasmate" is written in a white, bold, sans-serif font. The letter "G" is stylized, featuring a small circular icon with a flame or drop inside it.